



Beskrivelse	Modell HWT	Spenning	Max strømtrekk	Anbefalt sikringsstørrelse	Tilkoblingspunkt	
Utedel	Tilkobling	1101H(R)W-E 801H(R)W-E	220-240V -50 Hz	20.3A (MAX)	25A	(L, N) TB03
		601HW-E 401HW-E	220-240V -50 Hz	14.6A (MAX)	16A	
		1401XWHM3W-E 1101XWHM3W-E 601XWHM3W-E	220-240V -50 Hz	13A	16A	
Hydro Unit innedel	Tilkobling Backup varmer	1401XWHM6W-E 1101XWHM6W-E 601XWHM6W-E	220-240V -50 Hz	26A	32A	(L, N) TB02
		1401XWHT6W-E 1101XWHT6W-E	380-415V	13A (13Ax2P)	16A	
		1401XWHT9W-E 1101XWHT9W-E	380-415V	13A (13Ax3P)	16A	
		Tilkobling VVB - Hydro Unit	220-240V - 50 Hz	12A	16A	
Utedel - Hydro Unit	Tilkobling				(1, 2, 3) TB01	
VVB føler - Hydro Unit	Tilkobling				(1, 2) TB02	

